



For use in plasterboard and cavity walls, in different sizes to suit varying wall depths.

## HOLLOW WALL ANCHORS - with screws

Code	Size	Screw Diameter	Anchor Length	Wall Thickness	Fastens Up To	Hole Diameter	Qty Per Box	Weight Kg Per 100	Price £ Per 100
0840T450020	M4 X 20	4	20	0-5	8	8	100	0.51	<b>19.93</b>
0840T450032	M4 X 32	4	32	3-12	16	8	100	0.51	<b>21.72</b>
0840T450040	M4 X 38	4	38	10-16	17	8	100	0.85	<b>21.30</b>
0840T450050	M4 X 46	4	46	16-24	30	8	100	1.21	<b>24.41</b>
0840T470040	M5 X 37	5	37	6-13	17	10	100	1.30	<b>28.40</b>
0840T470065	M5 X 65	5	65	14-32	26	10	100	1.55	<b>30.03</b>
0840T490052	M6 X 52	6	52	3-16	30	13	50	1.95	<b>30.69</b>
0840T490065	M6 X 65	6	65	14-32	26	13	50	2.05	<b>32.68</b>



Use unique setting tool for fast repetitive fixings.

## HOLLOW WALL ANCHOR SETTING TOOL

Code	Description	Qty Per Box	Weight Kg Per Item	Price £ Per Item
0840TSET	Hollow Wall Anchor Setting Tool	1	0.45	<b>22.51</b>



Light duty fixing, ideal for ceiling installations and gives high loadings because of its wide wing coverage.

## SPRING TOGGLES - Complete with screws


Code	Thread Diameter	Screw Size	Wall Thickness	Cavity Depth	Hole Size	Rec Tensile Load kN	Qty Per Box	Weight Kg Per 100	Price £ Per 100
0862M390050	3	50	30	20	11	0.10	100	0.52	<b>22.64</b>
0862M470050	5	50	20	30	14	0.18	100	1.27	<b>27.03</b>
0862M470075	5	75	45	30	14	0.18	50	1.62	<b>27.03</b>
0862M470100	5	100	70	30	14	0.18	50	1.88	<b>33.21</b>
0862M490075	6	75	45	30	18	0.30	50	2.55	<b>37.29</b>

## SPRING TOGGLE - Wings only


Code	Thread Diameter	Screw Size	Wall Thickness	Cavity Depth	Hole Size	Rec Tensile Load kN	Qty Per Box	Weight Per 100	Price £ Per 100
0862M39	3	-	-	20	11	0.10	100	0.34	<b>14.65</b>
0862M47	5	-	-	30	14	0.18	100	0.63	<b>17.30</b>
0862M49	6	-	-	30	18	0.30	50	0.97	<b>23.97</b>




Light duty fixing, ideal for ceiling installations and gives high loadings because of its wide wing coverage.




Drill your hole to the correct diameter...



...tap fixing ensuring anti-rotation...



...attach setting tool to screw...



...remove screw and position fixture.